

Work Order	3353.2_Rev2
Setup-Code	200115-10290-2801-01



## Test Report

### JIS Z 2801:2012 (Mod)

**Antimicrobial products – Test for antimicrobial activity and efficacy**

#### **Test Object:**

*AIRDAL<sup>®</sup> versus Staphylococcus aureus DSM21979 EDCC 5247 after 225 days of artificial aging*

Work Order	3353.2_Rev2
Setup-Code	200115-10290-2801-01

## Report on Findings

**Client:** Decorative Products GmbH  
**Address:** Kurt-Fischer-Str. 32  
 22926 Ahrensburg  
 Germany

**Work order no.:** 3353.2\_Rev2

**Test object:** AIRDAL® versus *Staphylococcus aureus* DSM21979 EDCC 5247 after 225 days of artificial aging

**Sample description:** Coated foil

**Date of receipt of sample:** 23.05.2019

**Type of test:** JIS Z 2801:2012 Antimicrobial products – Test for antimicrobial activity and efficacy

**Test Germ:** *Staphylococcus aureus* DSM21979 EDCC 5247

**Test laboratory:** QualityLabs BT GmbH

**Address:** Neumeyerstrasse 46a  
 90411 Nuremberg, Germany

**Setup-Code:** 200115-10290-2801-01

**Sample material:** Test plates

**No. of pages in report:** 7

**Report on findings to the client:** **Place and date of preparation:** Nuremberg, 28<sup>th</sup> of February 2020  
**Recipient:** Decorative Products GmbH  
**This revision replaces the test report from the 27<sup>th</sup> of January 2020**

**Laboratory Director:** \_\_\_\_\_  
 Harald Gerauer, Laboratory Director  
 QualityLabs BT GmbH

**Released:** \_\_\_\_\_  
 Markus Zehe, Managing Director  
 QualityLabs BT GmbH

Work Order	3353.2_Rev2
Setup-Code	200115-10290-2801-01

---

## Declaration on Quality Assurance

This investigation was performed and supervised according to the standard operating procedure "SOP zu JIS Z 2801:2012 (Mod)" by QualityLabs BT GmbH. The laboratory and process are continually monitored by independent, external authorities, as well as by internal audits.

## Archiving

A copy of the test report, a protocol of the measurement as well as the accompanying correspondence and business records are archived by QualityLabs BT GmbH. The retention period is at least 10 years.

## Test description

Anti-bacterial activity is determined in accordance with a modified version of JIS Z 2801:2012.

During the test, a thin liquid-film containing the bacteria ( $1.25 \times 10^4$  CFU / cm<sup>2</sup>) is applied directly to the test sample (Standard: 5 cm x 5 cm). To avoid desiccation a foil (Standard: 4cm x 4cm, Stomacher Bags) is applied. Immediately after inoculation, the bacteria from the reference sample are separated from the sample and the enveloping foil surfaces using ultrasound and vortex devices and the number of viable germs (CFU – colony-forming units) is determined ( $t_0$  value). A further set of reference samples and samples given anti-microbial treatment is incubated with bacteria in a liquid-film and the enveloping foil in a damp environment at 37°C. After 24 hours, the bacteria are separated from the sample surfaces using ultrasound and vortex devices and the number of viable germs is determined ( $t_{24}$  value).

Work Order	3353.2_Rev2
Setup-Code	200115-10290-2801-01

### Assessment of antimicrobial activity

A logarithmic germ reduction of  $\geq 3$  log scales of the antimicrobial sample in comparison to the respective reference is used as assessment criterion to pass the antimicrobial test.

Germ reduktion [log scales]	Antibacterial activity
< 3	Not sufficient antimicrobial activity
$\geq 3$	Sufficient antimicrobial activity

Work Order	3353.2_Rev2
Setup-Code	200115-10290-2801-01

## References to Testconditions

Testconditions		
Sample size	25	cm <sup>2</sup>
Foil size	16	cm <sup>2</sup>
Volume Inoculum	400	μl
Sample cleaning	-	-

## References to deviations, preincubations, special test conditions

The samples were stored for 225 days at 50 °C.

Work Order	3353.2_Rev2
Setup-Code	200115-10290-2801-01

## Test Results

Sample Name	Sample Code	t <sub>0</sub> (cells/cm <sup>2</sup> )			t <sub>24</sub> (cells/cm <sup>2</sup> )			Reduction [%]	Log Reduction
1 Reference sample	102902805190017	4.7 x 10 <sup>4</sup>	5.8 x 10 <sup>4</sup>	5.8 x 10 <sup>4</sup>	1.5 x 10 <sup>5</sup>	1.5 x 10 <sup>5</sup>	1.7 x 10 <sup>5</sup>	-	Reference
2 AIRDAL®	102902805190018				< 1.0 x 10 <sup>1</sup>	< 1.0 x 10 <sup>1</sup>	< 1.0 x 10 <sup>1</sup>	> 99.99	> 4

\*see "Interpretation of Results", page 6

Test strain	<i>Staphylococcus aureus</i> DSM21979 EDCC 5247
Initial cell count inoculum / cm <sup>2</sup>	1.25 x 10 <sup>4</sup>
Initials of the editor	MZ
Measurement ended on	Jan-27-2020

Work Order	3353.2_Rev2
Setup-Code	200115-10290-2801-01

---

### Comments on test objects

NONE

### Interpretation of the results based on the measurements

NONE

**Editor:** Mr. Zehe \_\_\_\_\_

**Crosschecked:** Mr. Shendi \_\_\_\_\_

### References

JIS Z 2801:2012 Antimicrobial products – Test for antimicrobial activity and efficacy